Matrix ONE Instruction Manual

Getting started:

- 1) Fully charge the speaker before first use. Plug speaker into any computer USB port-Red indicates the speaker is being charged. Blue means the speaker is fully charged.
- 2) To pair speaker with phone through Bluetooth, flip the switch on the bottom of the speaker to Bluetooth mode. "Disconer bluetooth devices" through your device menue-enter "0000" for the pairing password.
- 3) To connect the speaker directly to your device, flip the switch on the bottom of the speaker to "LINE" mode.. Connect your device and speaker with the included "auxiliary/charge cable".
- 4) Open up the speaker by twisting it! Now fully enjoy the amount of bass that you get in this wonderful blend of Bluetooth wireless technology, size and precise acoustic engineering. Enjoy!

Playback Controls:

- 1) To increase or decrease the volume of the speaker, tilt & hold the rocker switch to the left to decrease the volume and to the right to increase the volume.
- 2) To skip to the next track or previous track, tilt & release the rocker switch to the left for the previous track and to the right for the next track.
- 3) To play or pause a track, press & release the rocker switch in its neutral position.

Speakerphone controls:

- 1) getting a phone call? While your phone is ringing, tilt & release the rocker switch to the right to answer the call! Once you're done, simply press & release the rocker switch while its in its neutral position to hang up!
- 2) Making a call? Just make the call on your phone and talk towards the speaker! It'll work just like that!